



Introduction to High Temperature Superconductors

An Online Continuing Education Course for Engineers

Course Number: E-1006

Credit: 1 Hour / 1 PDH / 1 CPD

Introduction to High Temperature Superconductors (1 PDH)

Author: Danny R. Graves, MSEE, PE

Introduction

High temperature superconductors (HTS) and their characteristics are fascinating topics. I hope that students that take this course will be inspired to experiment with superconductors. Perhaps the student may be the one that develops a *room* temperature superconductor and changes the world!

In this course, the student will be introduced to the fundamental properties of superconductors, the basics of high temperature superconductors, the Meissner effect, the zero resistance effect, practical experimentation kits, how to make a superconductor from scratch, applications for superconductors, and superconductor patent information.

Superconductors in General

A superconductor is a material that has zero resistance to electrical current when it is cooled to a certain temperature. What's the big deal? Electrical resistance causes things to be heavier and less efficient. In other words, it costs money. So, if you get rid of electrical resistance, you save lots of money. Using superconductors can also result in a smaller size for equivalent power in equipment. For example, using superconductor windings in electromagnets can increase the Tesla rating for a given physical size.

Superconductors also exhibit strange properties such as excluding all magnetic fields from their interiors. This is called the Meissner effect. It results in magnets *levitating* above a piece of superconductor material! This is truly a strange effect. It is magical except there is no trickery. It is very real.

You get conductors to become *super*conductors by cooling them. Any conductor will superconduct if cooled enough. Unfortunately, the required temperature is often very close to absolute zero (-273 C) or 0 degrees Kelvin (K) which is the lowest temperature that is theoretically possible. For example, around 100 years ago it was discovered that liquid Helium could make superconductors out of materials such as Mercury. Liquid

Helium has a temperature of 4.2K or only 4.2 degrees above the coldest temperature possible in the universe. Liquid Helium is not very practical or cheap. Higher temperature superconductors were needed.

High Temperature Superconductors (HTS)

High Temperature superconductors (HTS), which were discovered in the 1980s, will exhibit superconductor properties at much higher temperatures than that of liquid Helium. In fact, relatively cheap and easily obtainable liquid Nitrogen (LN₂) will sufficiently cool a HTS. LN₂ has a boiling point of -196 C. This is still very cold but much easier to accomplish than -273 C! Really, they should be called *relatively* high temperature superconductors since the temperatures involved are not high by any means.

One of the most popular HTSs is Yttrium-Barium-Copper-Oxide (YBCO). It is a ceramic material that is an insulator at room temperature. You read that correctly. It is an electrical *insulator* at room temperature but when you cool it with LN₂ it becomes a perfect *conductor* of electricity. Strange stuff!

One drawback to current HTS material is that it is brittle. It is difficult to make a flexible wire out of the current HTS materials. The brittleness is a very big hindrance to practical usage. This manufacturing difficulty (increased labor and wasted material) can make equipment that uses HTS material more expensive than ordinary versions of the equipment. HTS wire can be ordered from companies such as American Superconductor, <http://www.amsuper.com/products/htsWire/index.cfm>

Vendors such as FutureScience, Inc. (<http://www.futurescience.com>) will sell you fairly cheap kits that contain a small disk of YBCO, rare earth magnet, tweezers, Styrofoam cups to hold LN₂, etc. LN₂ is not included with the kits but you can get it from your local industrial/medical gas supplier (see Figure 1). LN₂ usually costs about \$2/gallon in small quantities. LN₂ can be safely handled if proper procedures are followed. However, if you get careless with LN₂, it can hurt you.

With these superconductor kits, you can check the conductance of the YBCO disk with a common continuity meter at room temperature to verify that it is, in fact, an insulator. Once cooled with LN₂, you can check the continuity of the YBCO disk again to verify that it has now turned into a conductor. You can also experiment with the unusual characteristics of superconductors such as the Meissner effect and the zero resistance effect.



Figure 1. A 10 liter LN2 container from Airgas (931-645-8276) in Clarksville, TN. As the LN2 warms, it changes back into the gas state. The loose fitting top prevents explosion. The LN2 lasts a surprisingly long time (several days) in this type/size container.

Meissner Effect

A substance that exhibits diamagnetism opposes a magnet similarly to the way two magnets faces of the same polarity oppose each other. A superconductor exhibits perfect diamagnetism since they exclude magnetic fields from their interiors. When a superconductor repels a magnet that is placed on it prior to cooling, it is called the Meissner effect. The effect is named for one of its discoverers, W. Meissner. This effect results in a magnet being levitated above a superconductor (or vice versa depending on which one is fixed). When the superconductor disk is cooled with LN2, the magnet actually rises (levitates) to a position above the disk from a resting position on top of the superconductor disk.


Zero Resistance

If a magnet is placed on the superconductor disk *after* the disk is cooled, the zero resistance effect is demonstrated as opposed to the Meissner effect. This will result in the

magnet floating above the superconductor disk. The physical height at which a magnet floats above the superconductor disk due to zero resistance is higher than the levitation height that is achieved with the Meissner Effect. Figure 2 and Figure 3 show the zero resistance effect in action floating a neodymium-iron-boron magnet above a disk of YBCO superconducting material.



Figure 2. Neodymium-iron-boron magnet floating about .25" above a LN2 cooled yttrium-barium-copper-oxide superconductor. When I poured about a quarter of a cup of LN2 into the Styrofoam cup, the levitation effect lasted, amazingly, for almost 15 minutes before it needed a boost from another shot of LN2.



To view the remainder of the course material and to take the quiz for PDH credit, you must purchase the course.

Close this window and click "Add to cart" on the product page.

Figure above

.25"

Makin

Oak
<http://v>
of supe.
covers t
your ow

and
also
ke

To m... basically combine the yttrium oxide/copper oxide/ba... the mixture, cool the mixture, grind the mixture, heat the mixture, cool the mixture, press the mixture into a pellet, and heat the mixture. Of course, it is really more complicated than this but well within the capability of an individual with basic chemistry knowledge and equipment. The details of the procedure can be seen at <http://www.ornl.gov/reports/m/ornlm3063r1/pt7.html>.